






Wiring Diagram and Dimension



Temperature Sensor

Temperature and Humidity Sensor



Head Office

TELIMA AG / NENUTEC
 Schachenstrasse 80, Ch-8645, Jona, Switzerland
 Tel: +41 55 224 4060 Fax: +41 55 224 4069
 Email: info@telima.ch
 website: www.nenutec.com

Asia/Pacific

NENUTEC Asia Pacific Pte Ltd
 32 Upper Serangoon View
 #15-42 Singapore 534 209
 Tel: +65 6489 1815 Fax: +65 6489 1816
 Email: info@nenutecap.com
 http://www.nenutecap.com